

Multimedia Keyboard



1 is a multi-tap key. You can use it to enter the number '1', but it can also be pressed multiple times to enter punctuation.

When Num Lock is on, number keys can be used enter channel numbers, or multi-tap keys to input text in areas such as Search. Note: only the Number Pad (Num Lock on) and navigation keys are typically supported within On Demand Players.

When Scroll Lock is on, arrow keys can be used to navigate up, down, left and right.

